



715 West Colton Avenue
Redlands, CA 92374
Toll Free: (877) 793-6636
Phone: (909) 793-6636
FAX: (909) 793-7641

Email: sales@covington-engineering.com

MAGNETIC DISK ORGANIZER

INSTALLATION

1. Decide on the orientation (open to the left or right)
2. Install the clasp using a 5/32" allen wrench and a 3/8" wrench. **Note:** The clasp can be installed on the top or bottom and must be installed before hanging the MDO.
3. Find the support studs and mark the holes. Be sure to level them. (You will probably want to pre-drill guide holes to prevent the studs from splitting). Bolt to wall using at least a 5/16" x 2-1/2" lag bolt.



SPECIAL CARE INSTRUCTIONS

After the MDO has been properly installed, care should be taken to help prevent rust from forming on the pages, the disk, and the lap wheel. The MDO's pages are made of galvanized steel to help reduce rust, but it is important to clean and maintain these pages because they are not completely rust-resistant.

1. Always wipe or blow-dry the disks before hanging them up on the MDO.
2. Spray down each page with WD-40 or an equivalent lubricant. Do this periodically throughout the year.
3. At the end of the day, clean the lap wheel with a scotch bright pad and then apply WD-40 to the wheel's surface. This will help reduce the accumulation of rust on the wheel and keep disks in better shape.

