



vibrating lap

- 1 pad
- 2 bumper ring
- 3 pan #135
- 4 soft plug
- 5 spring rod locking set screw
- 6 locking thumb screw 1/4-20
- 7 intermediate plate #144
- 8 anchor screws 1/4-20
- 9 rubber stabilizer caps
- 10 outer motor bearing #br9903
- 11 spring rods
- 12 counter weight
- 13 8/32" motor nut with std washers
- 14 stabilizer tubes
- 15 universal motor plate
- 16 motor plate anchor bolts 1/4-20
x 3/4 h.h. with washers
- 17 base #143
- 18 motor #5K004 with cord

